Application Note

Subject : How to use HPUSBFW(USB DOS bootable format tool for Windows) to format you USB Pen-Drive.

|	
FAQ Document No: S12001	**Date: 2012/01/16**
Model Name. All	**Rev. A1**

Category: ☐General ☐H/W ■S/W ☐Others,

Purpose :

Provide required Pure DOS environment for Re-flash BIOS with USB Pen-drive.

1. Uncompress DriveKey_HPUSBFW.rar (.Zip) to your Desktop PC C:\DriveKey folder
2. Insert empty USB Pen-drive into your desktop PC USB Port. Please make sure only one partition on this USB Pen-drive.
3. Under Windows XP environment, click HPUSBFW.exe

Avalue Technology Inc.

7F, 228, Lian-Cheng Road, Chung Ho City, Taipei, Taiwan R.O.C.

www.avalue.com.tw	Avalue Europe	Avalue USA	BCM Advanced Research	Avalue China
sales@avalue.com.tw	sales.europe@avalue.com.tw	sales@avalue-usa.com	BCMSales@bcmcom.com	sales.china@avalue.com.cn
Tel:+886-2-82262345	Tel: +45-7025-0310	Tel: +1-732-578-0200	Tel: +1-949-470-1888	Tel: +86-21-5426-3399
Fax:+886-2-82262777	Fax: +45-4975-5026	Fax: +1-732-578-0250	Fax: +1-949-470-0971	Fax: +86-21-6495-0370

www.avalue.com.tw

4. Check Device name listed with the correct Pen-driver name and drive letter.

5. Fill Volume Label name with XXXX

6. Mark the Quick format

7. Mark the **"Create a DOS Startup disk"** and locate the **"Using DOS system files Located at" "C:\DriverKey"** by click the Browser icon.

8. Click Start button. And click Y for below POP up screen.

Avalue Technology Inc.   7F, 228, Lian-Cheng Road, Chung Ho City, Taipei, Taiwan R.O.C.

www.avalue.com.tw   Avalue Europe   Avalue USA   BCM Advanced Research   Avalue China
sales@avalue.com.tw   sales.europe@avalue.com.tw   sales@avalue-usa.com   BCMSales@bcmcom.com   sales.china@avalue.com.cn
Tel:+886-2-82262345   Tel: +45-7025-0310   Tel: +1-732-578-0200   Tel: +1-949-470-1888   Tel: +86-21-5426-3399
Fax:+886-2-82262777   Fax: +45-4975-5026   Fax: +1-732-578-0250   Fax: +1-949-470-0971   Fax: +86-21-6495-0370

www.avalue.com.tw

9. After couple seconds, the format complete message POP up.

10. Check the USB Pen-Drive, it will have 3 hidden files inside.

11. Copy the BIOS file (*.BIN), flash utility (AWD896.EXE) and Auto-flash batch file (*.BAT) into this bootable USB Pen-drive.

12. Put this USB Pen-drive into target PC USB Port.
13. Boot form target PC and into BIOS for change First Boot sequence to USB-HDD
14. Reboot target PC, it will show you "Microsoft ® Windows 98 DOS prompt"
15. Type"PMPC10.bat" and Press Enter key.
16. After BIOS flash completed, Reboot this target PC and Into BIOS for Loading Optimized Defaults.
17. Done.

Avalue Technology Inc.

7F, 228, Lian-Cheng Road, Chung Ho City, Taipei, Taiwan R.O.C.

www.avalue.com.tw	Avalue Europe	Avalue USA	BCM Advanced Research	Avalue China
sales@avalue.com.tw	sales.europe@avalue.com.tw	sales@avalue-usa.com	BCMSales@bcmcom.com	sales.china@avalue.com.cn
Tel:+886-2-82262345	Tel: +45-7025-0310	Tel: +1-732-578-0200	Tel: +1-949-470-1888	Tel: +86-21-5426-3399
Fax:+886-2-82262777	Fax: +45-4975-5026	Fax: +1-732-578-0250	Fax: +1-949-470-0971	Fax: +86-21-6495-0370

www.avalue.com.tw